


RS Link Function Multi-point measurement can be performed by connecting multiple EH or EV counters with RS Link cables.

■ RS Link for EH Counter

It is possible to connect a maximum of 10 counter units and handle up to 20 channels of multi-point measurement at a time.

For this connection use a dedicated RS Link cable (**02ADD950**, 0.5 m; **936937**, 1 m; **965014**, 2 m).

(The total length of RS Link cables permitted for the entire system is up to 10m.)



■ RS Link for EV Counter

It is possible to connect a maximum of 10* counter units and handle up to 60 channels of multi-point measurement at a time.

For this connection use a dedicated RS Link cable (**02ADD950**, 0.5 m; **936937**, 1 m; **965014**, 2 m).

(The total length of RS Link cables permitted for the entire system is up to 10 m.)

* The maximum number of counter units that can be connected is limited to 6 (six) if an EH counter is included in the chain.

